


Application note: disconnecting graphics card in Airtop2 / Airtop3

- Make sure Airtop is disconnected from power
- Open the service door by pressing the top-bar
- Disconnect rigid-flex PCIe adapter from motherboard
 - Open two screws using an Allan hex key #2.5



- Pull out rigid flex PCIe adapter



- Press latch on graphics card 12V cord and pull out the connector